



## expansion boxes for diffusers KW/RD i KW/RDM

### INSTALLATION

Expansion boxes SR/ KWRD are designed for installation between the ceiling and underslung ceiling,. Prepare an installation hole of a size of  $\text{ØD}$  or  $A \times A$ . The box can be mounted onto the ceiling by appropriate hangers (bars, pins...) and installation slings.

Upon customer's request, boxes can be equipped with

1. factory slings
2. a crossbar that allows for installation of the front panel with one central screw

